

IXW-MA Door Release Flow Chart



**IX or IXG Master Station
or App**

Door release request sent



Door release request
accepted, built-in
contact is fired



IX Door Station

SIF signal sent when built-in contact is fired



SIF signal received,
door station identified



IXW-MA

Programmed dry output changes state



Door release system
activated by dry output

